

INSTRUCTIONS FOR LIGHTS:

The lights are turned on and off by twisting the light. However, there is a small piece of paper inserted to preserve battery life that needs to be removed before you can begin using the light.

STEP 1: Remove and discard the clear plastic ring around the light fixture.

STEP 2: Turn the light upside-down with the top of the light fixture facing the ground.

STEP 3: Carefully unscrew the top section of the light fixture (the part with the bulb) from the lower section of the light fixture (the part that attaches to the base platform). Be careful because the batteries are stored in the section with the bulb and may fall out.

STEP 4: There should be a round white piece of paper sitting on top of the battery. This piece of paper was placed there to prevent the battery from making contact with the lower section prior to use.

STEP 5: With the round white piece of paper removed, screw the upper and lower sections of the light fixture back together. When you fully tighten the fixture, the bulb should shine bright.

STEP 6: Insert the tab located on the bottom of the light fixture into the rectangular opening of your custom USS Flagg base piece. It should be a snug fit and sit flush on the base.

STEP 7: Place your new custom light pieces on your USS Flagg, show your friends, and wait for the oohs and aahs.

TROUBLESHOOT 1: If the light looks dim, it is possible that the batteries are not creating a strong contact. Loosen the two sections and shake the fixture while holding it upside-down to make sure the batteries are making contact with the bulb side of the fixture. Tighten to see if it solved the problem.

TROUBLESHOOT 2: If the batteries fall out, no worries! Make sure you don't lose the clear plastic piece that wraps around the three tiny batteries. If the clear plastic piece has come out, simply roll it up and place it back into the upper section of the fixture. Then begin to place the three batteries back into the fixture, one at a time. Make sure you can read the LR41 + side as you place it into the fixture.

BATTERY REPLACEMENT: The brightness of the bulb depends on how long you leave them on. If you leave the light on for a few hours, it will dim but will continue to work. If you need to replace the batteries, there are several options available on Amazon. You will want to search for LR41 batteries. Make sure you don't lose the clear plastic piece that wraps around the batteries while changing them.

LIGHT BULB REPLACEMENT: Light bulbs can be found on Amazon: "Acme Non-Blinking LED Balloon Light, LED Party Lights, LED Paper Lantern Light, LED Mini Light for Party or Wedding Decoration." You can find a direct link through my website at www.chrisdortch.com.



WEBSITE: www.chrisdortch.com

EMAIL: chris@chrisdortch.com

Visit my website and select “USS Flagg” on the menu to find additional resources. If you have any questions, don’t hesitate to email me at chris@chrisdortch.com.